CHRONO MOD®

OCEANMASTER

USER GUIDE

Rotating bezel, sapphire case back

CHRONO MOD
22
AUTOMATIC
50
10
40
20
30

WELCOME

ASSEMBLED BY HAND. BUILT JUST FOR YOU.

Your OceanMaster was assembled by hand, piece by piece, to the configuration you chose.

This booklet is written for this watch alone: its crown, its calibre, its rotating bezel, what it can take in water and how to care for it.

For any question, the workshop answers at contact@chrono-mod.com.

The Chrono Mod workshop

CONTENTS

01	Your OceanMaster in detail	4
02	Setting the time and date	6
03	Timing with the bezel	8
04	Water	9
05	Bracelet and care	10
06	Specifications	11
07	Warranty	12

01 Your OceanMaster in detail

41 mm brushed 316L steel case, transparent sapphire case back, domed sapphire crystal, unidirectional ceramic bezel. TMI NH35 automatic calibre with date.

1. **Triangle marker**: set it opposite the minute hand when you start timing.
2. **Date window.**
3. **Screw-down crown**: three positions, winding, date, time.
4. **Bracelet or strap**, depending on your build.
5. Hour **markers**.
6. Hour and minute **hands**.
7. **Unidirectional rotating bezel** in ceramic, graduated over 60 minutes.

41	3	NH35
MM	ATM	CALIBRE

1
2
3
4
5
6
7
CHRONO MOD
AUTOMATIC
22
10
20
30
40
50

02 SETTING YOUR OCEANMASTER

The crown

0
Against the case, screwed down: wearing and winding

1
One click: the date

2
Two clicks: the time; the seconds hand stops

UNSCREW, SCREW BACK

Before any setting, unscrew the crown (towards you) until it springs free: it is then in position 0.

Afterwards, push it back against the case and screw it fully down, without forcing. Left unscrewed, it no longer keeps water out.

WINDING BY HAND

When worn, your OceanMaster winds itself with the motion of your wrist. Stopped: crown unscrewed, in position 0, 20 to 30 turns clockwise, then wear it. A full wind takes at least 55 turns. Power reserve: about 41 hours.

TIME AND DATE, STEP BY STEP

NH35 calibre · date

1. Unscrew the crown, pull it to position 2 and bring the hands to 6 o'clock: from 9 pm to 4 am, the date mechanism is engaged.
2. Push the crown in to position 1. Turn it counter-clockwise to yesterday's date.
3. Pull the crown to position 2 and move the hands forward: the date changes at midnight. Carry on to the exact time, morning or afternoon.
4. Push the crown back against the case and screw it fully down.

END OF THE MONTH

The date counts 31 days. After a shorter month, advance it by one on the 1st (position 1, outside 9 pm to 4 am).

Recommended start: 6 o'clock

03 TIMING WITH THE BEZEL

Unidirectional bezel · 60 minutes

Dashed: the minute hand at the start, opposite the triangle, then 20 minutes later

1. At the start, turn the bezel (it only turns one way) until the triangle sits opposite the minute hand.
2. Time passes: the minute hand moves along the bezel scale.
3. Read the elapsed time opposite the minute hand: here, 20 minutes.

WHY ONLY ONE WAY

If knocked, the bezel can only turn the way that lengthens the time shown: you think more time has passed, never less. Out of the water: your OceanMaster is water-resistant to 3 ATM. Its bezel times cooking, parking, a meeting.

04 WATER: WHAT YOUR OCEANMASTER CAN TAKE

3 ATM

30 m

TRANSPARENT SAPPHIRE CASE BACK

Rain, splashes, washing hands	YES
Swimming	NO
Shower	NO
Sauna	NO

Despite its diver looks, your OceanMaster is not made for water: its bezel measures time, it is not for diving.

A transparent sapphire case back holds less pressure than a steel back: no swimming or showering with this watch.

05 BRACELET AND CARE

YOUR BRACELET

If you gave us your wrist size before assembly, the bracelet is already sized: the links removed are tucked into the box, with the sizing tool.

On a steel bracelet, the clasp closes in two moves: the blade folds under the cover and the two ends meet, then your thumb folds the polished cover over and clips it shut.

To change the strap: a spring-bar tool, and a 20 mm strap, the width between the lugs of your OceanMaster. Unsure how to adjust it? The workshop will do it: write to us.

CARE

Avoid shocks and magnets (speakers, magnetic clasps, phone cases). A magnetised watch runs wrong: a watchmaker demagnetises it in a minute.

Soft cloth; lukewarm soapy water on steel or rubber, never on leather.

No swimming: your sapphire case back is rated 3 ATM.

IN THE BOX *Your watch, its presentation box, the bracelet sizing tool and this booklet.*

06 SPECIFICATIONS

CASE	41 mm, brushed 316L steel
DIAL	31 mm
LUG WIDTH	20 mm
CRYSTAL	domed sapphire
CASE BACK	transparent sapphire
BEZEL	ceramic, unidirectional rotating, 60 minutes
WATER RESISTANCE	3 ATM (30 m)
MOVEMENT	TMI NH35, automatic, date
POWER RESERVE	about 41 hours; full wind in at least 55 turns
CROWN	screw-down
WARRANTY	2 years on the movement

07 · WARRANTY AND SUPPORT

YOUR WARRANTY

2-year movement warranty, from the day you receive the watch. Straps, bracelets, clasps and spring bars, shocks and wear are not covered. Your statutory rights (legal guarantee of conformity) apply in addition.

A problem? Write to contact@chrono-mod.com with your order number and a photo. Before having your watch opened by a watchmaker, write to us. Full terms: chrono-mod.com/pages/garantie.

Full terms
chrono-mod.com/pages/garantie

CHRONO MOD®

ASSEMBLED BY HAND. BUILT JUST FOR YOU.

CONTACT@CHRONO-MOD.COM · CHRONO-MOD.COM