



CLASSIC DATE

USER GUIDE

Automatic, magnified date





WELCOME

ASSEMBLED BY HAND. BUILT JUST FOR YOU.

Your Classic Date was assembled by hand, piece by piece, to the configuration you chose.

This booklet is written for this watch alone: its crown, its calibre, the movement that matches its dial, what it can take in water and how to care for it.

For any question, the workshop answers at contact@chrono-mod.com.

CONTENTS

01	Your Classic Date in detail	4
02	Setting the time and date	6
03	Which calibre is in your Classic Date?	8
04	Water	9
05	Bracelet and care	10
06	Specifications	11
07	Warranty	12

The Chrono Mod workshop

01 Your Classic Date in detail

36 or 39 mm 316L steel case, solid steel case back, sapphire crystal with date magnifier. The movement depends on the dial you chose: TMI NH35 (date), Miyota 8285 (day-date), NH35A (no date), NH70 or NH72 (skeleton).

- 1 **Magnified date:** the sapphire crystal carries a magnifier over the window.
- 2 **Screw-down crown:** winding, date (or day and date), time.
- 3 **Bracelet or strap,** depending on your build.
- 4 **Seconds hand:** it stops when the crown is pulled all the way out (NH35).
- 5 **Hour markers.**
- 6 **Hour and minute hands.**
- 7 **Fluted bezel.**

36 · 39 10 NH35 · 8285

MM

ATM

BY DIAL



02 SETTING YOUR CLASSIC DATE

The crown



0

Against the case,
screwed down: wearing
and winding



1

One click: date, or day
and date



2

Two clicks: the time

UNSCREW, SCREW BACK

Before any setting, unscrew the crown (towards you) until it springs free: it is then in position 0.

Afterwards, push it back against the case and screw it fully down, without forcing. Left unscrewed, it no longer keeps water out.

WINDING BY HAND

When worn, your Classic Date winds itself with the motion of your wrist. Stopped: crown unscrewed, in position 0, 20 to 30 turns clockwise, then wear it. Power reserve: about 41 hours (about 42 hours on the Miyota 8285).

TIME AND DATE, STEP BY STEP

NH35 calibre · date

- 1 Unscrew the crown, pull it to position 2 and bring the hands to 6 o'clock: from 9 pm to 4 am, the date mechanism is engaged.
- 2 Push the crown in to position 1. Turn it counter-clockwise to yesterday's date.
- 3 Pull the crown to position 2 and move the hands forward: the date changes at midnight. Carry on to the exact time, morning or afternoon.
- 4 Push the crown back against the case and screw it fully down.

DEPENDING ON YOUR DIAL

These steps are for the date dial (NH35). Day-date, no-date or skeleton: page 8. After a short month, advance the date by one on the 1st.



Recommended start: 6 o'clock

03 WHICH CALIBRE IS IN YOUR CLASSIC DATE?

The movement depends on the dial you chose

DIAL	CALIBRE	POSITION 1	RESERVE
Date	TMI NH35	the date, counter-clockwise	about 41 h
Day- Date	Miyota 8285	counter-clockwise: the date; clockwise: the day; in position 2 the seconds hand may keep running, which is normal	about 42 h
No date	NH35A	not used: position 2 only	about 41 h
Skeleton	NH70 or NH72	the time (only click), no date	about 41 h

All share the same screw-down crown and the same rule: never set the date between 9 pm and 4 am; on the day-date dial, no day change before 4:30 am. Unsure about your dial? Write to us with your order number.

04 WATER: WHAT YOUR CLASSIC DATE CAN TAKE

10 ATM

100 m

CLOSED STEEL CASE BACK

Rain, splashes, washing hands

YES

Swimming at the surface, crown screwed down

YES

Scuba diving

NO

Hot shower, sauna: steam gets past the gaskets

NO

Crown screwed fully down before water. After salt water, rinse with fresh water.

05 BRACELET AND CARE

YOUR BRACELET

If you gave us your wrist size before assembly, the bracelet is already sized: the links removed are tucked into the box, with the sizing tool.

On a steel bracelet, the clasp closes in two moves: the blade folds under the cover and the two ends meet, then your thumb folds the polished cover over and clips it shut.

To change the strap: a spring-bar tool, and a 20 mm strap, the width between the lugs of your Classic Date. Unsure how to adjust it? The workshop will do it: write to us.

CARE

Avoid shocks and magnets (speakers, magnetic clasps, phone cases). A magnetised watch runs wrong: a watchmaker demagnetises it in a minute.

Soft cloth; lukewarm soapy water on steel or rubber, never on leather.

After salt water, rinse with fresh water, crown screwed down.

IN THE BOX *Your watch, its presentation box, the bracelet sizing tool and this booklet.*

06 SPECIFICATIONS



CASE	36 or 39 mm, 316L steel
DIAL	28.5 mm
LUG WIDTH	20 mm
CRYSTAL	sapphire, with or without date magnifier (depending on the dial)
CASE BACK	solid steel
WATER RESISTANCE	10 ATM (100 m)
MOVEMENT	depending on the dial: TMI NH35 (date), Miyota 8285 (day-date), NH35A (no date), NH70 or NH72 (skeleton)
POWER RESERVE	about 41 hours (about 42 hours on the Miyota 8285)
CROWN	screw-down
WARRANTY	2 years on the movement

YOUR WARRANTY

2-year movement warranty, from the day you receive the watch. Straps, bracelets, clasps and spring bars, shocks and wear are not covered. Your statutory rights (legal guarantee of conformity) apply in addition.

A problem? Write to contact@chrono-mod.com with your order number and a photo. Before having your watch opened by a watchmaker, write to us. Full terms: chrono-mod.com/pages/warranty.



Full terms
chrono-mod.com/pages/warranty



ASSEMBLED BY HAND. BUILT JUST FOR YOU.

CONTACT@CHRONO-MOD.COM · CHRONO-MOD.COM