CHRONO MOD®

HORIZON

USER GUIDE

Integrated bracelet, sapphire case back




CHRONO MOD
22
AUTOMATIC

WELCOME

ASSEMBLED BY HAND. BUILT JUST FOR YOU.

Your Horizon was assembled by hand, piece by piece, to the configuration you chose.

This booklet is written for this watch alone: its crown, its calibre, its sapphire case back, what it can take in water and how to care for it.

For any question, the workshop answers at contact@chrono-mod.com.

The Chrono Mod workshop

CONTENTS

01	Your Horizon in detail	4
02	Setting the time and date	6
03	The sapphire case back	8
04	Water	9
05	Bracelet and care	10
06	Specifications	11
07	Warranty	12

01 YOUR HORIZON IN DETAIL

40 mm 316L steel case, transparent sapphire case back, 25 mm strap. NH35 automatic calibre (date) or NH38 on the Horizon Open Heart (no date).

1. **Date window** (Horizon with date; the Open Heart has none).
2. **Screw-down crown**: three positions, winding, date, time.
3. **Integrated bracelet**.
4. Hour **markers**.
5. Hour and minute **hands**.
6. **Octagonal bezel** with rounded corners.

40 MM

3 ATM

NH35 · NH38 CALIBRE


6
5
4
1
2
3
CHRONO MOD
22
AUTOMATIC

02 SETTING YOUR HORIZON

The crown



0
Against the case, screwed down: wearing and winding

1
One click: the date

2
Two clicks: the time; the seconds hand stops

UNSCREW, SCREW BACK

Before any setting, unscrew the crown (towards you) until it springs free: it is then in position 0.

Afterwards, push it back against the case and screw it fully down, without forcing. Left unscrewed, it no longer keeps water out.

WINDING BY HAND

When worn, your Horizon winds itself with the motion of your wrist. Stopped: crown unscrewed, in position 0, 20 to 30 turns clockwise, then wear it. A full wind takes at least 55 turns. Power reserve: about 41 hours.

TIME AND DATE, STEP BY STEP

NH35 calibre · date

1. Unscrew the crown, pull it to position 2 and bring the hands to 6 o'clock: from 9 pm to 4 am, the date mechanism is engaged.
2. Push the crown in to position 1. Turn it counter-clockwise to yesterday's date.
3. Pull the crown to position 2 and move the hands forward: the date changes at midnight. Carry on to the exact time, morning or afternoon.
4. Push the crown back against the case and screw it fully down.

HORIZON OPEN HEART

NH38 calibre, no date: position 2 only, for the time. Horizon with date, end of month: after a shorter month, advance the date by one on the 1st.



Recommended start: 6 o'clock

03 THE SAPPHIRE CASE BACK

Your NH35 (NH38 on the Open Heart) calibre, through the crystal



1. **Rotor**: it turns as you move your wrist and winds the watch.
2. **Balance**: it beats and regulates the rate.
3. **Transparent sapphire case back**: the reason for 3 ATM.

Turn your Horizon over: through the case back, you see its calibre at work.

Horizon Open Heart: its NH38 calibre also shows on the dial side, through an opening over the balance.

04 WATER: WHAT YOUR HORIZON CAN TAKE

3 ATM

30 m

TRANSPARENT SAPPHIRE CASE BACK

Rain, splashes, washing hands	YES
Swimming	NO
Shower	NO
Sauna	NO

A transparent sapphire case back holds less pressure than a steel back: no swimming or showering with this watch.

05 BRACELET AND CARE

YOUR BRACELET

Your Horizon's bracelet is integrated: it continues the case, with no visible spring bars.

If you gave us your wrist size before assembly, the bracelet is already sized: the links removed are tucked into the box, with the sizing tool.

Unsure how to adjust it? The workshop will do it: write to us.

CARE

Avoid shocks and magnets (speakers, magnetic clasps, phone cases). A magnetised watch runs wrong: a watchmaker demagnetises it in a minute.

Soft cloth; lukewarm soapy water on steel or rubber, never on leather.

No swimming: your sapphire case back is rated 3 ATM.

IN THE BOX *Your watch, its presentation box, the bracelet sizing tool and this booklet.*

06 SPECIFICATIONS



CASE	40 mm, 316L steel
DIAL	30.5 mm
LUG WIDTH	25 mm
CASE BACK	transparent sapphire
WATER RESISTANCE	3 ATM (30 m)
MOVEMENT	NH35, automatic, date; NH38 on the Horizon Open Heart, no date
POWER RESERVE	about 41 hours; full wind in at least 55 turns
BRACELET	integrated
CROWN	screw-down
WARRANTY	2 years on the movement

07 · WARRANTY AND SUPPORT

YOUR WARRANTY

2-year movement warranty, from the day you receive the watch. Straps, bracelets, clasps and spring bars, shocks and wear are not covered. Your statutory rights (legal guarantee of conformity) apply in addition.

A problem? Write to contact@chrono-mod.com with your order number and a photo. Before having your watch opened by a watchmaker, write to us. Full terms: chrono-mod.com/pages/warranty.

Full terms
chrono-mod.com/pages/warranty

CHRONO MOD®

ASSEMBLED BY HAND. BUILT JUST FOR YOU.

CONTACT@CHRONO-MOD.COM · CHRONO-MOD.COM